

FDT Plans

Pg. 1

VER 1

Upper

Base Plate

Axial Arms, Upper
Gimbal Mount and
Stabilizer Block all
mount to this Base

Attachment points
for Axial Arms

Attachment points
for Axial Arms

Drill all attachment point holes
with 3/16 in. bit. unless
otherwise noted

Stabilizer Block

Upper Gimbal Mount

Drill Both
parts with
5/16" bit.

Use a 5/16" carriage bolt, flat
washer and wing-nut for the
Gimbal pivot
brake.

Lower Gimbal Mount

All components to
be fabricated from
18mm. thick stock .
Attach all components together
with 1 1/4 in. x # 8 AP Screws